#### Experiment - 2

#### **Basic Concepts in OpenCV Image and Video Handling**

#### Aim:

- 1. To code the following tasks in OpenCV
  - a) To read and display an image by using OpenCV
  - b) To resize an image using OpenCV
- 2. To capture video from Camera, play a video from a file and save a video file.

#### **Software/ Package Used:**

- 1. Pycharm IDE
- 2. Libraries used:
  - a) NumPy
  - b) opency-python
  - c) matplotlib
  - d) scipy

#### **Programs:**

- 1. Read and Display image using OpenCV:
  - a) Read and display

```
# import all the libraries
import cv2 as cv
import sys

#load an image using imread function
img=cv.imread(r" C:/Users/21r228\Downloads\download.jpg ")
print(img)

#image not found
if img is None:
    sys.exit("Could not read the image")

#display the image
cv.imshow("Final",img)
k=cv.waitKey(0)
l=cv.destroyAllWindows()
```

## **Input : Color image**



# Output: Color image



# Image matrix in form of pixels

[[[255 255 255]

[255 255 255]

[255 255 255]

# b) Colour to Grayscale image

#import all libraries
import cv2 as cv
import sys

#load an image
img=cv.imread(r" C:/Users/21r228\Downloads\download.jpg ",0) # 0 indicates
grayscale
print(img)
if img is None:
 sys.exit("Could not read the image") #image location not found

#display the image in grayscale
cv.imshow("Final",img)
k=cv.waitKey(0)
l=cv.destroyAllWindows()

### **Input: Color image**



### **Output: Grayscale image**



### **Image matrix**

[[ 0 0 0 ... 252 254 254]

[ 0 0 0 ... 252 254 254]

[ 0 0 0 ... 252 254 254] ...

[ 49 45 42 ... 246 247 250]

[61 56 52 ... 246 247 250]

[ 76 70 65 ... 246 247 250]]

#### a) Write an image

```
import cv2 as cv
import sys
# Load an image
image =cv.imread(r" C:/Users/21r228\Downloads\download.jpg ",0) # image path
# Check if the image was successfully loaded
if image is not None:
    # Display the image in a window
    cv.imshow("Dark", image) # name of the output window
else:
    print("Image not found") # image not found in target location
k = cv.waitKey(0)
if k == ord('s'):
    cv.imwrite(r" C:/Users/21r228\Downloads\download.jpg ", image)
    cv.destroyAllWindows() # Close all OpenCV windows
```

**Input: Colour image** 



# **Output: Saved image**



#### 2. Resize an Image Using OpenCV:

```
# import all the libraries
import cv2 as cv
import sys
# load an image
img=cv.imread(r" C:/Users/21r228\Downloads\download.jpg ")
# resize the image using scaling factor
img2=cv.resize(img,(0,0),fx=0.5,fy=0.5)
# resize the image by varying the width and height of the image
img3=cv.resize(img,(300,500))
if img is None:
  sys.exit("Could not read the image") # image location not found
# display the output
cv.imshow("Original",img)
cv.imshow("Scaling Factor",img2)
cv.imshow("Bigger",img3)
k=cv.waitKey(0)
# display the height, width and channels of the images
dim= img.shape
print("Dimensions of original image:",dim)
print("Height: ",img.shape[0])
print("Width:",img.shape[1])
print("Channels: ",img.shape[2],"\n")
dim1= img2.shape
print("Dimensions of scaled factor image:",dim1)
print("Height: ",img2.shape[0])
print("Width: ",img2.shape[1])
print("Channels: ",img2.shape[2],"\n")
dim2= img3.shape
print("Dimensions of resized image:",dim2)
print("Height: ",img3.shape[0])
print("Width: ",img3.shape[1])
print("Channels: ",img3.shape[2])
```

## <u>Input:</u>




# Output:

# a) Original image



## b) **Scaled image**





### c) Varying the parameters



### **Shape of the images**

Dimensions of original image: (250, 150, 3)

Height: 250 Width: 150 Channels: 3

Dimensions of scaled factor image: (178, 100, 3)

Height: 178 Width: 100 Channels: 3

Dimensions of resized image: (500, 300, 3)

Height: 500 Width: 300 Channels: 3

#### 3. Video Handling

a) Read, display, Gray scaling, resizing of the video

```
#import all libraries
import cv2 as cv
import sys
# connection between the camera and the system
cap=cv.VideoCapture(0)
while cap.isOpened():
 ret,frame = cap.read()
 if not ret:
    print("cannot receive frame(stream end?).Exiting..")
#display the video
 cv.imshow("camera",frame)
 if cv.waitKey(1)==ord("q"):
   break
#convert colour video to grayscale video
 gray=cv.cvtColor(frame,cv.COLOR_BGR2GRAY)
 cv.imshow("gray",gray)
# resize the video
 res=cv.resize(frame,(1050,640)) # by varying the parameters
 res1=cv.resize(frame,None,fx=2,fy=1) # using scaling factor
#display the resized video
 cv.imshow("bigger",res)
 cv.imshow("scaled",res1)
cap.release()
cv.destroyAllWindows()
```

### Input:

From the USB camera

#### Output:



Output: Grayscale video



Output: Resized video by varying the parameters



Output: resized video by using scaling factors




### 4. Writing the video

```
import cv2
#import the video
video= cv2.VideoCapture(C:/Users/21r228\Downloads/tech [MConverter.eu].mp4')
#read the video
success,image = video.read()
count = 0
success = True
while success:
 success,image = video.read()
 frame_width = int(video.get(3))
 frame_height = int(video.get(4))
 size = (frame_width, frame_height)
 result = cv2.VideoWriter('filename.avi',
             cv2.VideoWriter_fourcc(*'MPEG'),10, size)
 cv2.imwrite("frame%d.jpg" % count, image) # save frame as JPEG file
 cv2.imshow('Frame',image)
if cv2.waitKey(10) == 27: # exit if Escape is hit
   break
 count += 1
```

### **Input:**



### **Output: Saved in file**





### 5. Split and Merge Image

```
import cv2
image = cv2.imread("C:/Users/21r228\Downloads\download.jpg")
(b_channel, g_channel, r_channel) = cv2.split(image)

#display the images
cv2.imshow('blue channel',b_channel)
cv2.imshow('green channel',g_channel)
cv2.imshow('red channel',r_channel)
# merge the image

image_merged = cv2.merge((b_channel,g_channel,r_channel))
cv2.imshow('merged image',image_merged)
cv2.waitKey(0)
cv2.destroyAllWindows()
```

# Input Image:



# **Output Image:**

# **Split Image:**

RED GREEN BLUE







**MERGED IMAGE:** 



Raghul	T - 21R228	
--------	------------	--

Department of RAE					
Criteria	Excellent (75% - 100%)	Good (50 - 75%)	Poor (<50%)		
Preparation (30)					
Performance (30)					
Evaluation (20)					
Report (20)					
Sign:		Total (100)			

## Result:

The basics of OpenCV Image and Video Handling were learnt using OpenCV- python in Pycharm IDE.

